
PHYSICAL DOLL INSTRUCTION MANUAL

Thank you for your support and trust in our company, and to purchase our physical doll series products, for your daily maintenance and use, we recommend that you read this manual before use, so that you can master the use method and dolls maintenance points.

[PRODUCT DESCRIPTION]

The outer layer of this product is made of new polymer materials, and the inner layer is made of epoxy resin and various metal joints. The product materials meet the relevant safety standards stipulated by the state. There is no poison to the human body or the environment. Please use it with confidence. There are various joints inside the body of the physical doll, and various postures can be posed within a certain range, so as to avoid deformation and damage of a certain rubber material due to long-term pulling. side (do not let the doll stand if it is not a standing style), the manufacturer will not be responsible for any damage to the doll caused by abnormal use.

AVAILABLE RANGE OF DOLLS




[HEAD INSTALLATION]

THE INSTALLATION METHOD OF THE HEAD IS AS FOLLOWS:




1. There are two types of head screws: full screw screws and buckle screws



3. Full screw screw installation: install the screw clockwise into the head, and then install it clockwise on the doll's neck.



2. Screw the screw on the head first





4. Buckle screw installation: install it clockwise into the head, and then press it directly against the screw hole on the neck.

SMART DIALOGUE

Please use standard Mandarin and speak as slowly as possible to ask the following questions

- 1. Where do you come from
- 4. You are so beautiful
- 7. What do your parents do
- 10. Do you love me
- 13. you got big boob

19. see you again

- 16. Do you want a condom

2. May I have your name

- 5. What do you like best
- 8. I'm in a bad mood
- 11. I miss you so much
- 14. Let's go for a fuck
- 17. Higher voice

- 3. How old are you
- 6. What would you like to eat
- 9. Am I handsome man
- 12.Let me hug you
- 15. Do I have a big cock
- 18. Lower voice





The speech function of the pronunciation machine

1. Long press the switch light and then release your hand to enter the voice function

2. Touch pronunciation: Equipped with a touch-sensitive sound chip, it can make a panting sound as you knead the doll, and it can reach an orgasm, giving you the same feeling as a real person. Note: [Voice function needs to be purchased and customized]

The installation method is as follows:







4. There is a gap during installation, swing the mortise lock left and right to the top position, and it is completed.

The split method is as follows:

[SPLIT FUNCTION INSTALLATION AND DISASSEMBLY METHO]



1. Put the doll in a flat position



the buckle inside and push up, and pull back with the other hand.

4. Done. 3. Until the leg splicing is separated


Notice: [The split function needs to be purchased and customized]

3. Push straight forward

[HEATING FUNCTION]

1. How to use warming: place the doll in a flat position, connect the power adapter, connect one end of the adapter to the doll heating interface, and connect the other end to the household electricity, then thedoll will be in a heating state. After about 45 minutes, the power was manually cut off. At this time, a comfortable temperature will be generated inside the doll. It can be used after power off. (Special attention: the dollcan only be heated when it is lying flat before heating),

- 2. Input voltage: input voltage 110V-250V wide voltage
- 3. Output voltage: 24V/48V
- 4. Heating time: 60-90 minutes, depending on the thickness of the doll, you can appropriately increase the heating time (less than 1 hour) or wrap thewhole body of the physical doll with a blanket (heating is less than 40 minutes) to achieve rapid heating effect.
- 5. Heat preservation time: The heat preservation time of the lower epidermis is 80 minutes to 120





minutes. Note: [The heating function needs to be purchased and customized]

[PRECAUTIONS FOR HEATING]

- 1. The maximum temperature of the doll is about 38 degrees Celsius, which is equivalent to the temperature of the human body. It is strictly forbidden to use physical dolls during the heating process. You must cut off the power and unplug the plug and use your fingers to detect the temperature of the lower body and the surface of the doll to ensure that the temperature is suitable (the lower body is not cold), can only be used under the premise that it will not cause harm to the user.
- 2. The charger should be placed in a ventilated place for heating. It is forbidden to heat up when it is covered with anything. During charging and heating (within the specified heating time), if the charger is found to be too hot (more than 70 degreesoutside the temperature tolerance range), please unplug the main power plug of the charger immediately to stop charging and heating, and continue heating at intervals of 10 minutes. If the temperature is found to be too hot again Please do not use it if it is high, and send it back to the manufacturer for replacement.
- 3. It is strictly forbidden to heat up for more than 90 minutes on a single charge. In order to avoid the failure of the thermostat due to long-term heating, the temperature will continue to rise, and the damage to the doll and otherproperty losses will be borne by the user.
- 4. Covering the blanket can achieve rapid heating. The time of covering the blanket during the heating process is not allowed to exceed 30 minutes, and the charging time for a single heating of the doll is not allowed to exceed 60 minutes, and the interval between two charges should be more than 40 minutes. 5. Occasionally, the temperature of the lower body of the doll does not rise enough, and it can be used together with a USB heating stick to achieve a rapid heating effect of the lower body.

Standing function: Compared with the conventional model, it can stand, and the posture is more diverse and flexible. Standing needs to rely on something.

Note: [Standing function needs to be purchased and customized]